

- 060..
- 065..
- 070..
- 071..
- 072..
- 074..
- 075..
- 076..
- 077..
- 078..
- 120..
- 125..
- 130..
- 131..
- 135..
- 136..
- 137..
- 138..
- 180..
- 181..
- 182..
- 183..
- 184..
- 190..


COMPATIBILITY:

QTV
FBLV/FCMV/FMEV
IRV/VLV
NI
DA
ET



1


Montaggio Assembly



$65 \pm 5^{\circ}\text{C}$



$15 \pm 5^{\circ}\text{C}$




MIN - MAX




OK

2 a




b




C


QTV




DA
ET




FBLV
FCMV
FMEV




IRV
VLV






NI




NI
072
074
076
078
180
182



3






Attacco Lavastoviglie
Dish Washer Machine Connection




CALDO
HOT

FREDDO
COLD







4 a



b









c




M

Manutenzione Service



S a




Sostituzione Vitone
How to Ceramic Disk Valve

**b**

Sostituzione Snodo
How to replace Joint

c

Sostituzione Aeratore
How to replace Aerator

**d**

Sostituzione Canna
How to replace Spout

e

QTV

