




010..

014..


015..

510..

514..

1


Montaggio Assembly



$65 \pm 5^{\circ}\text{C}$



$15 \pm 5^{\circ}\text{C}$




MIN - MAX




OK

2 a




b




- 010
- 014
- 015
- 510
- 514

c




d




3a

010
510




b

014
015
514




4




010
014
015
510
514


5






6



7







8
a



010
510





b



014
015
514




M

Manutenzione Service



R

Regolazione temperatura Temperature setting



S

Sostituzione Cartuccia termostatica

How to replace thermostatic cartridge






010

014

015

510

514



010

014

015

510

514

Sostituzione Deviatore e cartuccia

How to replace Diverter and cartridge