


010..

015..

018..

019..



COMPATIBILITY:

ELY

EL/EF

LES/LEC/LEA

BR

BI

LIG

RIN/WS

CA

SK

SY

GR

RED

DE

DU

ND

NT

PI

APM


FA/GI

TA

TI

RO

LM



1

Montaggio Assembly



$65 \pm 5^{\circ}\text{C}$



$15 \pm 5^{\circ}\text{C}$




MIN - MAX




OK

Fissaggio Leve Fixing Levers


a




b



c




d



2 a


010



3



Rispettare le uscite e non rimuovere i tappi
Respect the outlets and don't remove the plug



a




015

018

019




Rispettare le uscite e non rimuovere i tappi
Respect the outlets and don't remove the plug



USCITA PRINCIPALE

b





015

018

019

c

015




018

019




d

015










018



019






Posizioni maniglia e selezione uscite
Handle positions and outlets selection




Controlla di aver impostato correttamente
l'uscita superiore A quindi fissare la maniglia
Check to set up accurately A upper outlet and
than fix handle




018



015









A



B

M Manutenzione Service





Per tutte le serie
For all series



Solo per Elys
Only for Elys

Sostituzione Deviatore How to replace Diverter

CH_{2,5}CH_{2,5} $\text{CH}_{2,5}$

CH2,5

CH_{2,5}

015

018

019