

LIQ

LIQ168..

LIQ168D..


LIQ168E..

LIQ168ED..

LIQ169..

LIQ020..

LIQ022..





1



$65 \pm 5^{\circ}\text{C}$




$15 \pm 5^{\circ}\text{C}$



MIN - MAX



OK




Δp : differenza pressione in entrata
different inlet water pressure

2

168 020

168E 022

169




168 020


168E 022

169

020




022




168 020
168E 022
169


168







168ECO









169



168	020
168E	
169	022




Manutenzione
Service






Sostituzione Cartuccia Termostatica How to replace Thermostatic Cartridge

a





b

Sostituzione Sede Calotta How to replace Seat for Nut





C

Sostituzione Vitone Ceramico How to replace Ceramic Disc Valve

 CH17**d**

Sostituzione Vitone Ceramico con Ecostop How to replace ceramic disc valve with Ecostop

 CH17

e Sostituzione Deviatore
How to replace Diverter

